



CLUBSPORT STEERING WHEEL FITTING

- 1) REMOVE OLD WHEEL
- 2) REMOVE HORN PAD OFF CLUB SPORT WHEEL
- 3) REMOVE SILVER SCREWS FROM CONTACT PLATE (Not Black!)
- 4) REMOVE CONTACT PLATE
- 5) FIT WHEEL TO BOSS KIT
- 6) ATTACH HORN RING FROM OLD WHEEL TO BOSS KIT
- 7) REFIT HORN CONTACT
- 8) FIT WHEEL TO VEHICLE
- 9) REFIT HORN PAD

IT IS RECOMMENDED THAT YOU HAVE THE VEHICLE IN A POSITION WHERE YOU CAN DRIVE BACKWARDS AND FORWARDS A SHORT DISTANCE TO ENSURE THE FRONT WHEELS ARE STRAIGHT SO THAT THE STEERING WHEEL WILL ALSO BE ON STRAIGHT.

Note.

DO NOT REMOVE BLACK PHILIPS SCREWS FROM HORN CONTACT!