



THE PORSCHESHOP

Unit 4/Block 2
Shenstone Trading Estate
Mucklow Hill
Halesowen
West Midlands
B63 3XB

Tel: 0121 585 6088

Fax: 0121 503 0502

E-mail: yourcar@porscheshop.co.uk

Fitting Instructions for 944 5" Bridge Spoiler

1. Remove existing rear spoiler leaving the side pieces in place
(note you may need to drill out the existing screws)
2. Align the new bridge spoiler into place and mark through the holes in the tailgate frame.
3. Drill the new spoiler using a 1/8" (3.2mm) drill bit.
4. Apply bonding agent to spoiler base (optional)
5. fasten spoiler to tailgate frame with self tapping screws