



## **Fitting Instructions for 5" Bridge Spoiler**

1. Remove existing rear spoiler leaving the side pieces in place ( note you may need to drill out the existing screws )
2. Align the new bridge spoiler into place and mark through the holes in the tailgate frame.
3. Drill the new spoiler using a 1/8" ( 3.2mm ) drill bit.
4. Apply bonding agent to spoiler base ( optional )
5. fasten spoiler to tailgate frame with self tapping screws