



## **THE PORSCHESHOP**

Unit 4/Block 2  
Shenstone Trading Estate  
Mucklow Hill  
Halesowen  
West Midlands  
B63 3XB

**Tel:** 0121 585 6088

**Fax:** 0121 503 0502

**E-mail:** yourcar@porscheshop.co.uk

### **944 8V C.D.A ( Inc 924S ) For Cars 1982- 1989**

- 1, Remove existing air box and meter unit as one assembly.
- 2, Split the air box assembly and remove the 4 bolts securing the meter unit.
- 3, Fit the new rectangular flange bracket to the meter using 4 new screws.
- 4, refit the meter unit to the hose and add the new support bracket.
- 5, Remove the snorkel pipe from the air box cover and connect it to the inlet side of the CDA using the silicone joiner provided then secure with the 2 jubilee clips provided.
- 6, Replace the snorkel pipe back into the wing hole and mount the CDA to the near side inner wing ( Note. you will need to drill and mount the bracket ).
- 7, Form the hose ( provided ) into an "S" shape and connect to the engine side of the CDA and to the new meter bracket then secure with the 2 jubilee clips provided.
- 8, check for clearances to insure bonnet clearance etc.
- 9, Start & run Engine, Idle speed should be unchanged ( 900-1000rpm ).

Note. this kit will only work correctly provided all other serviceable elements to the car are correct & in good working order!