



THE PORSCHESHOP

Unit 4, Block 2
Shenstone Trad Est
Bromsgrove Rd
Halesowen
West Midlands
B63 3XB

Tel: 0121 585 6088
Fax: 0121 503 0502

E-mail: yourcar@porscheshop.co.uk

CDA Induction Kit for 911 Carrera 3.2 & 964 C2/C4 3.6 Years 1984-1994 (For Non Aircon cars only)

- 1 Unclip air box cover and remove air filter
- 2 Remove air box by unscrewing 10mm bolts
- 3 Fix the adaptor collar to airflow meter
- 4 Using bracket supplied fix one end to the CDA strap and other end to the cotton reel mounting boss on the inlet manifold, allowing the CDA to face rearward. (You may need to shape bracket as required)
- 5
Fit the silicone collar to the engine side of the CDA and using the black hose supplied, shape into a 90 degree loop And cut to length using either a hacksaw or Stanley knife. The hose should fit over the adaptor collar and inside the silicone collar, these should be secured with Jubilee clips. (Note; washing up liquid will help ease of fitting & clean silicone hose too)
- 6 Using the remaining piece of black hose supplied, curve this into 45 degrees and fit to the inlet side of the CDA ensuring it faces downwards and away from the engine fan & lid.

NB: Filters are pre-oiled and will only need cleaning and re-oiling every 24,000 miles.